




# Wired Liquid Level Acquisition

((((ECHOMETER)))


## 1 Connect Well Analyzer




## 2 Select Liquid Level



## 3 Pick Sensors



## 4 Zero the Pressure Sensor



When finished, close popup window to proceed with testing. Changes save automatically.

## 5 Install Sensors on Well



Well Analyzer Gas Gun & PT


Charge the gas gun 150-300 psi above surface pressure on the well.

Close the gun bleed valve.


Open casing valve between gun and wellhead.

Close casing valve to the flowline.

## 6 Start Acquisition



## 7 Results, Finish Pressure Buildup



## 8 Get Report

